SWITCH

ONE DESIGN BY E6E

Gooseneck Pin and Slot

- The Gooseneck Pin must be inserted into the slot as indicated by the red arrow in Figure 1.
- When inserted correctly into the slot, it should look like the image at Figure 2.

Figure 1.

Figure 2.